SCREWDRIVER

STRAIGHT HANDLE VERSION

- Srewdriver is started by the integrated auto trip valve.
- Switched off by adjustable friction clutch.
- To be connected to Powasert Screw Feeder.
- Length of screw feeding tube is about 4 meter.
- The screwdriver must not be used in rooms with explosive atmosphere.

Special equipment:
- Depth of drive control for exact depth of screw in case of variable strength of workpiece.

model	length (mm)	weight (kg)	speed (min $^{-1}$)	torque (Nm)	screw dimensions (mm)		
					head Ø	shaft Ø	length
ADS 2540	415	1,5	2400	5,1	6 - 8	3,0 - 4,0	10 - 35
ADS 2545	425	1,6	2400	5,1	7 - 9	3,5 - 4,5	10 - 45
ADS 3515	480	1,8	2400	5,1	8 -10	4,0 - 5,0	40 - 55

special dimensions on request

min. length = 1,5 x head diameter

Phillips

Torx

Pozidriv

headstyle selectable

B E S + S Gmbh

info@powasert.de
www.powasert.de

- POWASERT®
- Topseal - und Folien - Sicherheitsventile

Beratung • Ersatzteile • Service • Schraubtechnik

Obere Zeil 6 - 8 · 61440 Oberursel (Taunus) · ☎ 06171 98941-0 · 🖷 06171 98941-11